

LAN

PC				LAN			
LaVieT	LT700/ 2D	PC- LT7002D	1 / 2002	WindowsXP	Fn+F2		
	LT900/ 2D	PC- LT9002D					
	LT700/ 1D	PC- LT7001D	10 / 2001				
	LT900/ 1D	PC- LT9001D					
LaVieC	LC900/ 2D	PC- LC9002D	1 / 2002	WindowsXP	Fn+F2		
	LC700/ 1D	PC- LC7001D	10 / 2001				
	LC900/ 1D	PC- LC9001D					
	LC900/ J 84DH	PC- LC900J 84DH	7 / 2001				
		LC900/ J 84DB	PC- LC900J 84DB		ORINOCO Client Manager		
LaVieJ	LJ 700/ 2D	PC- LJ 7002D	1 / 2002	WindowsXP			
LaVieG C LAN	LG10 S/A	PC- LG10 SFEA	1 / 2002	WindowsXP	Fn+F2		
	LG10 S/9	PC- LG10 SFE9	10 / 2001				
	LG85 S/9	PC- LG85 SFE9					
	LG10 S/8	PC- LG10 SX58	7 / 2001				
		LG80 S/8	PC- LG80 SX58		ORINOCO Client Manager		
LaVieG T LAN	LG12 E/A	PC- LG12 EWEA	1 / 2002	WindowsXP	Fn+F2		
	LG10 E/A	PC- LG10 EWEA					
	LG10 E/9	PC- LG10 EWE9	10 / 2001				
	LG85 E/9	PC- LG85 EWE9					
		LG10 E/8	PC- LG10 EV58	7 / 2001	ORINOCO Client Manager		
		LG80 E/8	PC- LG80 EV58				
LaVieG M LAN	LG85 V/A	PC- LG85 VHEA	1 / 2002	WindowsXP			
	LG85 V/9	PC- LG85 VHE9	10 / 2001				
	LG80HV/ 9	PC- LG80HVHE9					
LaVieG J LAN	LG65HJ / A	PC- LG65HJ HEA	1 / 2002	WindowsXP			
	LG65HJ /A- P	PC- LG65HJ HJ A					
	LG80J / A	PC- LG80J HEA					
	LG80J /A- P	PC- LG80J HJ A					
VersaPro LAN	VA80/ BH	PC- VA80 BH*E	1 / 2002	WindowsXP			
	VA65H/ BH	PC- VA65HBH*E					
VersaPro LAN	VA80/ BL	PC- VA80 BL*E	1 / 2002	WindowsXP			
	VA65H/ BL	PC- VA65HBL*E					
VersaPro LAN	VA80/ VH	PC- VA80 VH*E	10 / 2001	WindowsXP	Fn+F2		
	VA60H/ VH	PC- VA60VH*E					
		VA70/ VH	PC- VA70 VH*D	7 / 2001		ORINOCO Client Manager	
		VA60H/ VH	PC- VA60VH*D				
VersaPro LAN	VA86H/ DF	PC- VA86HDF*E	1 / 2002	WindowsXP	Fn+F2		
	VA86H/ DX	PC- VA86HDX*E					
	VA12/ DG	PC- VA12 DG*E	10 / 2001				
	VA11J/ DF	PC- VA11J DF*E					
	VA10J/ DF	PC- VA10J DF*E					
	VA86J/ DF	PC- VA86J DF*E					
	VA80H/ DF	PC- VA80HDF*E					
	VA86J/ DX	PC- VA86J DX*E					
	VA80H/ DX	PC- VA80HDX*E					
	VA11J/ DF	PC- VA11J DF*D	7 / 2001				
		VA10J/ DF	PC- VA10J DF*D		ORINOCO		

* : 1

LaVieG LAN
VersaPro LAN